








Instalation manual

LORA: HANGER



1x z1	1x n26	1x f3 $\phi 10 \times 50$ mm	1x p17 $\phi 5 \times 60$ mm	2x p25 $\phi 3.5 \times 16$ mm
8x p6 $\phi 4 \times 35$ mm	10x r1 $\phi 15 \times 12$ mm $\phi 16$	10x r16	4x s2 $\phi 16$	1x y1 OLUB
6x e1 $\phi 7 \times 50$ mm	16x f1 $\phi 8 \times 30$ mm	4x k150	2x n301	4x p1 $\phi 3.5 \times 13$ mm





№					
1	l-401	2000	500	16	1
2	l-303	498	295	16	2
3	l-003	2000	100	18	1
4	l-203	500	350	16/32	1
5	l-204	500	350	16/32	1